



First Step




Ψ - value [W/mK] = **0.04**

Final Step



Ψ - value [W/mK] = **0.06**

COLOR CODE



DESCRIPTION/CHALLENGES

First step :
The combined insulation layer with PU board and aerogel guarantees warm interior surface temperatures at sill.

Second step :
EPS external wall insulation covers the existing sill